


**Important Electrical Information: Plug this unit into a dedicated outlet with no other electrical equipment running on the same outlet at the same time.**

Allow 1 hour for slushie to be fully ready.

To Prepare Drink Base:

1. Product may be made in batches at a ratio of 5:1 or all at once. To prepare all at once, mix entire contents of jug with 5 jugs of water.
2. Fill each side with prepared drink to the fill line.



To Prepare Slushie:

1. Set the Power Switch (A) on the right side to position "I".
2. Set the Mixer/Refrigeration Switches (B) on both sides to position "II" to prepare Slushie on both sides.
3. Set the Light Switch (E) to position "I".

\*Do not adjust the Temperature Switch. (D)

#### IMPORTANT TIPS TO REMEMBER:

Always keep the barrels filled above the slushie turning mechanism. As drinks are served and level lowers, add more prepared drink mix to refill. When product level falls below the turning mechanism, turn off the Mixer/Refrigeration Switches. Dump and clean drip trays as needed.

Never adjust the 2 grey knobs which have been pre-set.

Never use a dishwasher to clean any parts as it will damage them. Please use serving levers to empty any remaining product from machine for pick-up. Machine does not need to be cleaned for return.

**WARNING: MAY CAUSE BRAIN FREEZE!**