

POPCORN MACHINE INSTRUCTIONS



PLEASE READ FULLY BEFORE OPERATING.

- 1 TURN ALL SWITCHES LOCATED IN THE TOP LEFT CORNER OF THE POPCORN MACHINE TO 'ON'.
- 2 LET POPPING KETTLE HEAT FOR APPROXIMATELY 4 MINUTES (1ST BATCH ONLY).
- 3 RAISE THE COVER AND POUR IN THE PRE-MEASURED PACKETS OF OIL, SALT & POPCORN.
- 4 TURN KETTLE TO DUMP WHEN POPPING IS ABOUT 99% COMPLETED AND REPEAT IMMEDIATELY WITH NEXT PACKET. 5 PACKETS/CYCLES OF POPPING WILL FILL THE MACHINE.




FINAL POPPING

ON THE LAST SERIES OF POPPINGS, TURN OFF HEAT SHORTLY BEFORE POPPING IS COMPLETED. WHEN THE PAN HAS BEEN DUMPED, RETURN TO POPPING POSITION, CLOSE THE COVER, AND TURN OFF THE MOTOR. THIS WILL STOP SMOKING AND KEEP EXCESS OIL FROM BURNING ON THE PAN.



IMPORTANT:
NEVER LEAVE POPPING KETTLE HEAT OR
MOTOR ON WHEN NOT POPPING CORN.



CLEANING

TO AVOID EXTRA CLEANING CHARGES, WE ASK THAT YOU PLEASE REMOVE ANY EXCESS POPCORN FROM THE MACHINE AND WIPE POPPING KETTLE WITH A SOFT CLOTH WHILE IT IS STILL WARM.

LEFT OVER POPCORN?

NO PROBLEM! RETURN ANY UNUSED PACKETS OF POPCORN WITH YOUR MACHINE AND WE WILL BUY THEM BACK.

